



Originale	Sostituto
POWER	Power
SOURCE	Source
ASPECT	Eco / Aspect
FREEZE	Freeze / Timer
BLANK	Blank / Mute
MUTE	Shift + Blank / Mute
VOL+	Vol + / Page +
MENU	Menu
AUTO	Auto
VOL-	Vol - / Page -
PIP SIZE	Shift + Left
PIP SOURCE	Shift + Up
D.ZOOM+	+ / Play
PIP POS.	Shift + Right
RETURN	Volt / Focus
D.ZOOM-	- / Stop
KEYSTONE	Down

Originale	Sostituto
KEYSTONE UP	Up
EXIT	Mode



DOWN