



















| Originale | | Sostituto | | Originale | | Sostituto | |
|---|----------|---|--------|---|-------|---|--------------|
|  | Power |  | Power |  | 0 |  | 0 |
|  | Mute |  | Mute |  | Menu |  | Menu |
|  | FAV |  | Pre Ch |  | Exit |  | Exit |
|  | Subtitle |  | Subt |  | EPG |  | Guide |
|  | Info |  | Info |  | Swap |  | Media |
|  | TTX |  | Text |  | Up |  | Up |
|  | List |  | List |  | Down |  | Down |
|  | Recall |  | Back |  | Right |  | Right |
|  | 1 |  | 1 |  | Left |  | Left |
|  | 2 |  | 2 |  | OK |  | Ok |
|  | 3 |  | 3 |  | Vol+ |  | Vol + |
|  | 4 |  | 4 |  | Vol- |  | Vol - |
|  | 5 |  | 5 |  | Pg Up |  | Shift + Up |
|  | 6 |  | 6 |  | PG Dn |  | Shift + Down |
|  | 7 |  | 7 |  | CH+ |  | Ch + |
|  | 8 |  | 8 |  | CH- |  | Ch - |
|  | 9 |  | 9 |  | >> |  | >> |





| Originale | | Sostituto | | Originale | | Sostituto | |
|---|-----------------|---|---------|-----------|--|-----------|--|
|  | << |  | << | | | | |
|  | >> |  | >> | | | | |
|  | I<< |  | I<< | | | | |
|  | Play |  | Play | | | | |
|  | Pause/Timeshift |  | Pause | | | | |
|  | Stop |  | Stop | | | | |
|  | Rec |  | Rec | | | | |
|  | Audio |  | Dual | | | | |
|  | M/P |  | Smart | | | | |
|  | Tv/Radio |  | TV/R | | | | |
|  | A-B |  | Options | | | | |
|  | Red/Zoom |  | Red | | | | |
|  | Green/Aspect |  | Green | | | | |
|  | Yellow/V-Formet |  | Yellow | | | | |
|  | Blue/Timer |  | Blue | | | | |
| | | | | | | | |
| | | | | | | | |

