



| Originale | | Sostituto | | Originale | | Sostituto | |
|-----------|--------|-----------|-----------------------------|-----------|-------------|-----------|---------------|
| | Power | | Power | | 9 | | 9 |
| | Red | | Red / Netflix / Search | | 0/AV | | 0 |
| | Green | | Green / APP / Repeat | | P+ | | CH+ / Page+ |
| | Yellow | | Yellow / YouTube / Repeat | | P- | | CH- / Page- |
| | Blue | | Blue / Prime Video / Random | | Vol+ | | Vol+ |
| | [=+] | | Setup / OPT / | | Vol- | | Vol- |
| | [/=] | | AV / Input / RDS | | N/E | | OK |
| | [=x] | | Picture / Format | | Right | | Right |
| | [=] | | Text / Goto | | Left | | Left |
| | 1 | | 1 | | Up | | Up |
| | 2 | | 2 | | Down | | Down |
| | 3 | | 3 | | P/C | | Back / Return |
| | 4 | | 4 | | i | | Info / Angle |
| | 5 | | 5 | | Mute | | Mute / Dimmer |
| | 6 | | 6 | | Color- | | << / Tune- |
| | 7 | | 7 | | Color+ | | >> / Tune+ |
| | 8 | | 8 | | Brightness- | | I<< / Preset- |





























































| Originale | Sostituto | Originale | Sostituto |
|-------------|-----------------|-----------|-----------|
| Brightness+ | >> / Preset+ | | |
| Tint- | Display / Media | | |
| Tint+ | Smart / List | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |





| Originale | Sostituto |
|---|---|
|  Power |  Power |
|  Red |  Red / Netflix / Search |
|  Green |  Green / APP / Repeat |
|  Yellow |  Yellow / YouTube / Repeat |
|  Blue |  Blue / Prime Video / Random |
|  0/AV |  0 |
|  Vol+ |  Vol+ |
|  Vol- |  Vol- |
|  P+ |  CH+ / Page+ |
|  P- |  CH- / Page- |
|  Down |  Down |
|  Up |  Up |
|  N/E |  OK |
|  Right |  Right |
|  Left |  Left |
|  i |  Info / Angle |
|  Mute |  Mute / Dimmer |

| Originale | Sostituto |
|---|---|
|  Rec |  Rec / Rec Mode |
|  Stop |  Stop / Hold |
|  Pause |  Pause / Step / Freeze |
|  Play |  Play / Slow |
|  Tint- |  Display / Media |
|  Tint+ |  Smart / List |
|  << / Tune- |  << / Tune- |
|  >> / Tune+ |  >> / Tune+ |
|  Zoom / Size |  Zoom / Size |
|  I<< / Preset- |  I<< / Preset- |
|  >>I / Preset+ |  >>I / Preset+ |

