




























































Originale	Sostituto
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Recall	 Pre Ch
 Source	 AV
 Menu	 Menu
 P.Mode	 Shift + Format
 S.Mode	 Shift + Dual

Originale	Sostituto
 Exit	 Exit
 Display	 Shift + Info
 Enter	 Ok
 Up	 Up
 Down	 Down
 Left	 Left
 Right	 Right
 Vol+	 Vol +
 Vol-	 Vol -
 CH+	 Ch +
 CH-	 Ch -
 FAV/List	 Dual
 Freeze	 Options
 Tv/Radio	 TV/R
 Rec	 Rec
 Red	 Red
 Green	 Green



