



































































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Blue/[]	 Blue
 Vol+	 Vol +	 Info	 Info
 Vol-	 Vol -	 Text	 Text
 PR+	 Ch +	 1	 1
 PR-	 Ch -	 2	 2
 Mute	 Mute	 3	 3
 Menu	 Menu	 4	 4
 Exit	 Exit	 5	 5
 Back	 Back	 6	 6
 OK	 Ok	 7	 7
 Up	 Up	 8	 8
 Down	 Down	 9	 9
 Right/Zoom+	 Right	 0/-/--	 0
 Left/Zoom-	 Left	 AV	 AV
 Red/[o]	 Red	 SP/LP	 Media
 Green/Timer/List	 Green	 Play	 Play
 Yellow	 Yellow	 >>	 >>
































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Blue/[]	 Blue
 Vol+	 Vol +	 Info	 Info
 Vol-	 Vol -	 Text	 Text
 Mute	 Mute	 Play	 Play
 PR+	 Ch +	 Stop	 Stop
 PR-	 Ch -	 Rec	 Rec
 Exit	 Exit	 Pause	 Pause
 Menu	 Menu	 >>	 >>
 Back	 Back	 <<	 <<
 Up	 Up	 1	 1
 Down	 Down	 2	 2
 Right/Zoom+	 Right	 3	 3
 Left/Zoom-	 Left	 4	 4
 OK	 Ok	 5	 5
 Red/[o]	 Red	 6	 6
 Green/Timer/List	 Green	 7	 7
 Yellow	 Yellow	 8	 8





Originale	Sostituto	Originale	Sostituto
			
Power	Power	Blue/[]	Blue
			
Vol+	Vol +	Info	Info
			
Vol-	Vol -	Text	Text
			
Mute	Mute	1	1
			
PR+	Ch +	2	2
			
PR-	Ch -	3	3
			
Menu	Menu	4	4
			
Exit	Exit	5	5
			
Back	Back	6	6
			
Up	Up	7	7
			
Down	Down	8	8
			
Right/Zoom+	Right	9	9
			
Left/Zoom-	Left	0/-/--	0
			
OK	Ok	AV	AV
			
Red/[o]	Red	SP/LP	Media
			
Green/Timer/List	Green	Play	Play
			
Yellow	Yellow	Stop	Stop



