








































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Vol+	 Vol+
 TV/RAD	 TV/Radio /	 Mute	 Mute / Dimmer
 Input	 AV / Input / RDS	 PR+/Page Up	 CH+ / Page+
 AV Mode	 Picture / Format	 Vol-	 Vol-
 Energy Saving	 Eject / Surround	 PR-/Page Down	 CH- / Page-
 1	 1	 Up	 Up
 2	 2	 Left	 Left
 3	 3	 OK	 OK
 4	 4	 Right	 Right
 5	 5	 Menu	 Menu / Home
 6	 6	 Down	 Down
 7	 7	 Return	 Back / Return
 8	 8	 Red	 Red / Netflix / Search
 9	 9	 Green/Stop	 Green / APP / Repeat
 List	 Smart / List	 Green/Stop	 Stop / Hold
 0	 0	 Yellow/Play	 Yellow / YouTube / Repeat
 Q.View	 Display / Media	 Yellow/Play	 Play / Slow

Originale	Sostituto	Originale	Sostituto
 Power	 Power	 TV	 DVD
 TV/RAD	 DVD	 SAT	 AUX
 Input	 DVD	 SLOW	 STEP-FREEZE
 AV Mode	 DVD	 HOLD	 REC MODE
 Energy Saving	 DVD	 TUNE-	 TUNE+
 1	 DVD	 PRESET-	 PRESET+
 2	 DVD	 TITLE	 LANG UII
 3	 DVD	 EQ	 SURROUND
 4	 DVD	 SOUND	 AUDIO
 5	 DVD	 SUBTITLE	 TIMER
 6	 DVD	 FORMAT	 SIZE
 7	 DVD	 PICTURE	 ZOOM
 8	 DVD	 SLEEP	 PROGRAM
 9	 DVD	 TOP MENU	 OPT-TOOLS
 List	 DVD	 GOTO	 RDS
 0	 DVD	 D.MENU	 SETUP
 Q.View	 DVD	 TEXT	 AV INPUT
		 HOME	 ANGLE
		 MENU	 INFO
		 CLEAR	 RETURN
		 EXIT	 BACK
		 CANCEL	 LIST
		 VOL+	 SMART
		 VOL-	 MEDIA
		 TV	 DISPLAY
		 DVD	 CH PAGE
		 CD - STB	 TV
		 VIDEO	 TAPE
		 AUX - HDD	 TUNER
		 USB	 VIDEO
		 BLUETOOTH	 AUX - HDD
		 RETURN	 USB
		BACK	 BLUETOOTH
		NETFLIX	 RETURN
		Red	BACK
		Green/Stop	NETFLIX
		Green/Stop	Red
		APP	NETFLIX
		Green/Stop	NETFLIX
		HOLD	NETFLIX
		Stop / Hold	NETFLIX
		Yellow / YouTube / Repeat	NETFLIX
		Yellow/Play	NETFLIX
		Yellow/Play	NETFLIX
		Play / Slow	NETFLIX



