




































































Originale	Sostituto
 Power	 Power
 >>>	 +  Shift + Menu
 Source	 AV
 I - II	 Dual
 Subtitles	 Subt
 [i+]	 Info
 [?]	 D. Menu
 Mix	 TV/R
 Zoom	 Eject
 Time	 +  Shift + AV
 [PP]	 Back
 DNR	 Options
 Mosaic	 Guide
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left


Originale	Sostituto
 Red / Menu	 Red
 Red / Menu	 +  Shift + Format
 Green / Menu	 Green
 Green / Menu	 +  Shift + Dual
 Yellow / Other	 Yellow
 Yellow / Other	 Menu
 Blue / OK	 Blue
 Blue / OK	 Ok
 Special Audio	 +  Shift + Subt
 Text	 Text
 P -	 Ch -
 P +	 Ch +
 Vol -	 Vol -
 Vol +	 Vol +
 1	 1
 2	 2
 3	 3





































	Originale	Sostituto	Originale	Sostituto
	4			
	5			
	6			
	7			
	8			
	9			
	0			
	Mute			
	P < P			
	Format			
	Freeze			
	Smart Controls Picture			
	Smart Controls Audio			





Originale	Sostituto
 Power	 Power
 Time	 TV/R
 Zoom	 3D
 Mix	 Text
 [?]	 Shift + Info
 [i+]	 Info
 Freeze/Rec	 Pause
 Format/Stop	 Format
 Source	 AV
 I-II	 Dual
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Rec	 Rec
 <<	 <<
>>	>>

Originale	Sostituto
 Stop	 Stop
 Play	 Play
 Timer	 Shift + AV
 P-	 Ch -
 P+	 Ch +
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/--	 Guide

