



Originale		Sostituto		Originale		Sostituto	
	Power		Power		hold / EPG		Guide
	Mute		Mute		Red		Red
	1		1		Green		Green
	2		2		Yellow		Yellow
	3		3		Blue		Blue
	4		4		Vol +		Vol +
	5		5		Vol -		Vol -
	6		6		I-II		Dual
	7		7		Source		AV
	8		8		CH +		Ch +
	9		9		CH -		Ch -
	0		0		Sleep		Sleep
	Text		Text		Menu		Menu
	Back / S.Page		Back		DTV / Radio		TV/R
	index / PVR List		Smart		Exit		Exit
	reveal / REC		Rec		Aspect		Format
	zoom / T.Shift		Eject		Up		Up





Originale		Sostituto		Originale		Sostituto	
	Right		Right		<<		<<
	Down		Down		>>		>>
	Left		Left		FAV		Pre Ch
	OK		Ok		Repeat / Fav +		Shift + Right
	P.Mode		Shift + Format		A-B / Fav -		Shift + Left
	S.Mode		Shift + Dual				
	Media		Media				
	Slow / Info		Info				
	Slow / Info		Shift + Play				
	Step / Subtitle		Subt				
	Freeze		Shift + Stop				
	Step / Subtitle		Shift + Pause				
	Play / Pause		Play				
	Play / Pause		Pause				
	I<<		I<<				
	>>I		>>I				
	Stop		Stop				

