







Originale	Sostituto
 Power	 Power
 TDT / A	 Smart
 16:9 / B	 Format
 SAT / C	 Media
 AUX / D	 AV
 INF / E	 Info
 Sleep / F	 Sleep
 TV/RA	 TV/R
 EPG	 Guide
 Red / Text	 Text
 Green / Back	 Back
 Yellow / Subtitle	 Subt
 Blue / Audio	 List

Originale	Sostituto
 Blue / Audio	 Dual
 Up	 Up
 Left / Vol-	 Left
 Left / Vol-	 Vol -
 OK	 Ok
 Right / Vol+	 Right
 Right / Vol+	 Vol +
 Down	 Down
 Exit	 Exit
 Menu	 Menu
	 Ch -
	 Ch +
 1	 1
 2	 2
 3	 3





	Originale	Sostituto		Originale	Sostituto
	4				
	5				
	6				
	7				
	8				
	9				
	0				
	Pause				
	Mute				
	F1				
	F2				
	F3				
	F4				
	F5				

