

























































Originale	Sostituto	Originale	Sostituto
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Tv/Radio		TV/R
	←		Pre Ch
	Jezyk		Dual
	Obraz		Format
	CH+		Ch +

Originale	Sostituto	Originale	Sostituto
	CH-		Ch -
	Vol+		Vol +
	Vol-		Vol -
	Up		Up
	Down		Down
	Right		Right
	OK/i		Ok
	Left		Left
	X		Exit
	PVR		Back
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue/Ulubione		Blue
	Menu		Menu
	EPG		Guide
	Rec		Rec





Originale	Sostituto	Originale	Sostituto
 Cyfrowy/Polsat	 Smart		
 <<<	 <<<		
 Play	 Play		
 Pause	 Pause		
 Stop	 Stop		
 >>>	 >>>		

