













































































| Originale   | Sostituto  |
|---|--|
|  Power     |  Power                        |
|  Mute      |  Mute / Dimmer                |
|  1         |  1                            |
|  2         |  2                            |
|  3         |  3                            |
|  4         |  4                            |
|  5         |  5                            |
|  6         |  6                            |
|  7         |  7                            |
|  8         |  8                            |
|  9        |  9                           |
|  Home    |  Shift + Menu /             |
|  0       |  0                          |
|  YouTube |  Shift + Yellow / YouTube / |
|  Vol+    |  Vol+                       |
|  TV      |  TV/Radio /                 |
|  CH+     |  CH+ / Page+                |

| Originale   | Sostituto  |
|---|--|
|  Vol-      |  Vol-                             |
|  Source    |  AV / Input / RDS                 |
|  CH-       |  CH- / Page-                      |
|  USB       |  Shift + 8                        |
|  Option    |  Setup / OPT /                    |
|  Info      |  Info / Angle                     |
|  FAV       |  Fav / Marker / PC                |
|  Menu      |  Menu / Home                      |
|  EPG       |  Guide / EPG / -/--               |
|  Up        |  Up                               |
|  Left     |  Left                            |
|  OK      |  OK                             |
|  Right   |  Right                          |
|  Down    |  Down                           |
|  Back    |  Back / Return                  |
|  Exit    |  Exit / Cancel / Clear          |
|  Netflix |  Shift + Red / Netflix / Search |





| Originale  | Sostituto   |
|--|---|
|  Red    |  Red / Netflix / Search      |
|  Green  |  Green / APP / Repeat        |
|  Yellow |  Yellow / YouTube / Repeat   |
|  Blue   |  Blue / Prime Video / Random |
|  Sleep  |  Sleep / Timer               |
|  Zoom-  |  Shift + Zoom / Size         |
|  Zoom+  |  Zoom / Size                 |
|  List   |  Smart / List                |
|  Text   |  Text / Goto                 |
|  Sub    |  Subtitle / EQ               |
|  Recall |  Shift + Back / Return       |
|  Eco  |  Display / Media           |
|  <<<  |  <<< / Tune-               |
|  >>>  |  >>> / Tune+               |
|  I<<  |  I<< / Preset-             |
|  >>I  |  >>I / Preset+             |
|  Rec  |  Rec / Rec Mode            |

| Originale   | Sostituto   |
|---|---|
|  Play  |  Play / Slow           |
|  Pause |  Pause / Step / Freeze |
|  Stop  |  Stop / Hold           |
|  Audio |  Audio / Lang I/II     |

