































Originale	Sostituto
	Power
	Mute
	1
	2
	3
	4
	5
	6
	7
	8
	9
	0
	AV
	Tv
	TX
	Sel

Originale	Sostituto
	Smart / List
	CH+ / Page+
	CH- / Page-
	Up
	Down
	Right
	Left
	Vol+
	Vol-
	Info / Angle
	Sleep / Timer
	Setup / OPT /
	Zoom / Size
	Menu / Home
	Fav / Marker / PC
	Red / Netflix / Search
	Green / APP / Repeat





Originale	Sostituto
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	Subtitle / EQ
	Back / Return
	Picture / Format
	D.Menu / Top
	Display / Media
	Stop / Hold
	Audio / Lang I/II
	Sound / Title
	Exit / Cancel / Clear

Originale	Sostituto

