







































































| Originale | Sostituto | Originale | Sostituto |
|--|---|--|---|
|  Power |  Power |  NICAM |  VOD |
|  Mute |  MUTE |  Menu |  MENU |
|  1 |  1 |  Source |  SRC |
|  2 |  2 |  Up |  UP |
|  3 |  3 |  Down |  DOWN |
|  4 |  4 |  Right |  RIGHT |
|  5 |  5 |  Left |  LEFT |
|  6 |  6 |  OK |  OK |
|  7 |  7 |  Exit |  EXIT |
|  8 |  8 |  Display |  MEDIA |
|  9 |  9 |  Vol + |  VOL + |
|  0 |  0 |  Vol - |  VOL - |
|  -/-- |  -/-- / EPG |  List |  INFO |
|  Back |  BACK |  Fav List |  P/C / FAV |
|  P.Mode |  V-FOR |  CH + |  CH + |
|  S.Mode |  Audio |  CH - |  CH - |
|  Sleep |  Shift + Power |  TV / Radio |  TV/R |



