



Originale	Sostituto
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 PgUp	 Ch +
 PgDn	 Ch -
 FAV+	 >>I
 FAV-	 I<<
 Up/CH+	 Up

Originale	Sostituto
 Down/CH-	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Vol+	 Vol +
 Vol-	 Vol -
 Menu	 Menu
 Exit	 Exit
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 EPG	 Guide
 Audio	 Dual
 SUB	 Subt
 Zoom	 Eject
 FAV	 Pre Ch



