







































































Originale		Sostituto		Originale		Sostituto	
	Standby		Power		Right		Right
	Rec PVR		Rec		Left		Left
	PVR List		List		OK		Ok
	Mute		Mute		Vol+		Vol +
	EPG		Guide		Vol-		Vol -
	Audio		Dual		1		1
	Info		Info		2		2
	TTX		Text		3		3
	Subtitle		Subt		4		4
	Menu		Menu		5		5
	Exit		Exit		6		6
	Favourite		Pre Ch		7		7
	Tv/Radio		TV/R		8		8
	CH+		Ch +		9		9
	CH-		Ch -		0		0
	Up		Up		Recall		Back
	Down		Down		Goto		AV





	Originale	Sostituto
	<<	<<
	>>	>>
	<<	<<
	>>	>>
	Play	Play
	Pause	Pause
	Stop	Stop
	Repeat	+ Shift + Text
	Red	Red
	Green	Green
	Yellow	Yellow
	Blue	Blue

Originale	Sostituto

