





Originale		Sostituto		Originale		Sostituto	
	Power		Power		Red/Music		Red
	Sleep		Sleep		Blue/Game		Blue
	CBL/SAT		1		Yellow/Pure		Yellow
	DVD		2		Info		Info
	Blu-ray		3		Option		Options
	Game		4		Back		Back
	AUX		5		Setup		Menu
	iPod/USB		6		Up		Up
	Tv Audio		7		Down		Down
	FM		8		Right		Right
	Network		9		Left		Left
	Internet Radio		TV/R		Enter		Ok
	Channel+		Ch +		Volume+		Vol +
	Channel-		Ch -		Volume-		Vol -
	Page Up		Subt		Mute		Mute
	Page Down		Dual		Favorite Station 1		Text
	Green/Movie		Green		Favorite Station 2		AV





	Originale	Sostituto	Originale	Sostituto
	Favorite Station 3	 Format		
	I<</Tune-	 I<<		
	Tune+>>I	 >>I		
	Play	 Play		
	Pause	 Pause		

