














































Originale	Sostituto
 Sleep	 Sleep / Timer
 Power OFF	 Shift + Power
 Power On	 Power
 Disc	 Shift + 1
 Tuner	 Shift + 6
 USB1/iPod	 Shift + 8
 AUX	 Shift + 7
 1	 1
 2	 2
 3	 3
 Rand	 Shift + Blue / Prime
 4	 4
 5	 5
 6	 6
 Repeat	 Shift + Green / APP /
 7	 7
 8	 8

Originale	Sostituto
 9	 9
 A-B	 Shift + Yellow / YouTube /
 0	 0
 SRCH	 Shift + Red / Netflix /
 Clear	 Exit / Cancel / Clear
 CH+	 CH+ / Page+
 Mute	 Mute / Dimmer
 Vol+	 Vol+
 CH-	 CH- / Page-
 Setup	 Setup / OPT /
 Vol-	 Vol-
 Top Menu	 Shift + D.Menu / Top Menu
 Up	 Up
 Menu/Pop Up	 D.Menu / Top
 Left	 Left
 Enter	 OK
 Right	 Right





Originale	Sostituto
 Home	 Menu / Home
 Down	 Down
 Return	 Back / Return
 <</Tuning-	 << / Tune-
 Play	 Play / Slow
 >>/Tuning+	 >> / Tune+
 I<<	 I<< / Preset-
 Pause	 Pause / Step / Freeze
 Stop	 Stop / Hold
 >>I	 >>I / Preset+
 RDS/Audio	 Audio / Lang I/II
 Subtitle	 Subtitle / EQ
 Angle	 Info / Angle
 Pic In Pic	 Picture / Format
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat

Originale	Sostituto
 Blue	 Blue / Prime Video / Random
 S.Direct	 TV/Radio /
 SDB Tone	 Fav / Marker / PC
 Dolby	 Guide / EPG / -/-
 Stereo	 Sound / Title
 Display	 Display / Media
 Dimmer	 Shift + Mute / Dimmer
 Clock	 Shift + Sleep / Timer
 Power Tv	 Shift + OK
 Input Tv	 AV / Input / RDS
 Remote/Browse	 Smart / List
 Play/Pause	 Shift + Play /

