



Originale		Sostituto		Originale		Sostituto	
	Power		Power		OK		Ok
	Mute		Mute		Vol+		Vol +
	TV		Smart		Vol-		Vol -
	Tv/Rad		TV/R		Red/Multi Feed		Red
	Audio		Dual		Green		Green
	Aspect		3D		Yellow		Yellow
	USB		Media		Blue/Timer		Blue
	FAV		Pre Ch		EPG		Guide
	Exit		Exit		Info		Info
	Menu		Menu		Text		Text
	Back		Back		1		1
	P+		Ch +		2		2
	P-		Ch -		3		3
	Up		Up		4		4
	Down		Down		5		5
	Right		Right		6		6
	Left		Left		7		7



