



| Originale    | Sostituto |
|--------------|-----------|
| Standby      | Power     |
| Open / Close | Eject     |
| 1            | 1         |
| 2            | 2         |
| 3            | 3         |
| 4            | 4         |
| 5            | 5         |
| 6            | 6         |
| 7            | 7         |
| 8            | 8         |
| 9            | 9         |
| 0            | 0         |
| Goto         | Guide     |
| Add / Clear  | Exit      |
| <<           | <<        |
| >>           | >>        |
| Pause        | Pause     |

| Originale | Sostituto |
|-----------|-----------|
| Play      | Play      |
| Stop      | Stop      |
| I<<       | I<<       |
| >>I       | >>I       |
| Up        | Up        |
| Left      | Left      |
| Enter     | Ok        |
| Right     | Right     |
| Down      | Down      |
| Setup     | Options   |
| Navigat   | Smart     |
| Title     | List      |
| Menu      | Menu      |
| Subtitle  | Subt      |
| Angle     | Format    |
| Source    | AV        |
| Rec       | Rec       |



