









































Originale	Sostituto
 Power	 Power
 Mute	 Mute
 UHF	 Smart
 Pause	 Pause
 EPG	 Guide
 A-Z	 Media
 FAV	 Pre Ch
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0

Originale	Sostituto
 TV/Radio	 TV/R
 Menu	 Menu
 Back	 Back
 Exit	 Exit
 Info	 Info
 Up / CH+	 Up
 Up / CH+	 Ch +
 Down / CH-	 Down
 Down / CH-	 Ch -
 Right / Vol+	 Right
 Right / Vol+	 Vol +
 Left / Vol-	 Left
 Left / Vol-	 Vol -
 OK	 Ok
 Red / FTA/CAS	 Red
 Green / SAT	 Green
 Yellow / TV/SAT	 Yellow





Originale	Sostituto
Blue / A/V	Blue
Page+ / +100	>>
Page- / -100	<<
-	<<
+	>>
F1 / Zoom	ZOOM Eject
F2 / Sleep	SLEEP Sleep
F3 / PIP	PICTURE Format
F4 / Back	SETTINGS Options
F1 / Zoom	SHIFT + 1 Shift + 1
F2 / Sleep	SHIFT + 2 Shift + 2
F3 / PIP	SHIFT + 3 Shift + 3
F4 / Back	SHIFT + 4 Shift + 4
Text	REPEAT Text
Subtitle	AD Subt

Originale	Sostituto

