




































Originale	Sostituto
 Power	 Power
 TV Set Power	 Shift + Power
 TV Set V +	 Vol +
 TV Set V -	 Vol -
 Mute	 Mute
 TV Mode	 Options
 TV / Rad	 TV/R
 Find	 Media
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9

Originale	Sostituto
 0	 0
 Recall	 Back
 Audio	 Dual
 Menu	 Menu
 Exit	 Exit
 Up	 Up
 Right	 Right
 Down	 Down
 Left	 Left
 OK	 Ok
 Sat	 AV
 Fav	 Pre Ch
 PG +	 Ch +
 PG -	 Ch -
 YouTube	 Smart
 Play / PauInfo	 Info
 EPG	 Guide





Originale	Sostituto
 Play / Pause	 Play
 Play / Pause	 Pause
 << FB	 <<
 >> FF	 >>
 Stop	 Stop
 I<< Prev	 I<<
 >>I Next	 >>I
 Sleep	 Sleep
 Sub-T	 Subt
 Text	 Text
 Rec	 Rec
 Red / IPTV	 Red
 Green / Video	 Green
 Yellow / PVR	 Yellow
 Blue / Timer	 Blue

Originale	Sostituto

