


















Originale	Sostituto
 Power	 Power
 Tv Input	 +  Shift + AV
 Input	 AV
 Ratio	 Smart
 - *	 +  Shift + Left
 * +	 +  Shift + Right
 Simplink	 Media
 Sleep	 Sleep
 Text	 Text
 I/II	 Dual
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Stop	 Stop
 Play	 Play
 Pause	 Pause












































Originale	Sostituto
 I<<	 I<<
 <<	 <<
 >>	 >>
 >>I	 >>I
 Exit	 Exit
 List	 List
 Menu	 Menu
 Q.View	 Options
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Vol+	 Vol +
 Vol-	 Vol -
 FAV	 Pre Ch
 Mute	 Mute









Originale		Sostituto		Originale		Sostituto	
	Power		Power		4		4
	Stop		Stop		5		5
	Play		Play		6		6
	Pause		Pause		7		7
	<<		<<		8		8
	l<<		l<<		9		9
	>>		>>		0		0
	>>l		>>l		Vol+		Vol +
	Menu		Menu		Vol-		Vol -
	Up		Up		Mute		Mute
	Down		Down				
	Right		Right				
	Left		Left				
	OK		Ok				
	1		1				
	2		2				
	3		3				



