





































| Originale | Sostituto |
|---|---|
|  Power |  Power |
|  Open/Close |  Eject |
|  AV |  AV |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  Title |  Options |
|  Dubbing |  Pre Ch |
|  <</Backward |  << |
|  >>/Forward |  >> |

| Originale | Sostituto |
|---|---|
|  I<< Skip |  I<< |
|  Skip >>I |  >>I |
|  Pause/Step |  Pause |
|  Play |  Play |
|  Stop |  Stop |
|  Disc Menu/List |  List |
|  Setup |  Menu |
|  Display |  Info |
|  Return |  Back |
|  Up/PR-TRK+ |  Up |
|  Down/PR-TRK- |  Down |
|  Right |  Right |
|  Left |  Left |
|  Enter |  Ok |
|  O)))/Audio |  Dual |
|  [...] /Subtitle |  Subt |
|  Zoom |  Shift + Eject |







































| Originale | | Sostituto | |
|---|-----------|---|--------------|
|  | Clear |  | Exit |
|  | Rec |  | Rec |
|  | Rec Mode |  +  | Shift + Rec |
|  | Timer Rec |  +  | Shift + AV |
|  | CHP.ADD |  | Format |
|  | A-B |  | 3D |
|  | Play Mode |  +  | Shift + Play |
|  | Thubnail |  | Text |
|  | TV-VCR |  | TV/R |
|  | Marker |  | Smart |
|  | Search |  +  | Shift + TV/R |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Originale | | Sostituto | |
|-----------|--|-----------|--|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |





| Originale | Sostituto |
|---|---|
|  Power |  Power |
|  Open/Close |  Eject |
|  AV |  AV |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  Title |  Options |
|  Dubbing |  Pre Ch |
|  <</Backward |  << |
|  >>/Forward |  >> |

| Originale | Sostituto |
|---|---|
|  I<< Skip |  I<< |
|  Skip >>I |  >>I |
|  Pause/Step |  Pause |
|  Play |  Play |
|  Stop |  Stop |
|  Disc Menu/List |  List |
|  Setup |  Menu |
|  Display |  Info |
|  Return |  Back |
|  Up/PR-TRK+ |  Up |
|  Down/PR-TRK- |  Down |
|  Right |  Right |
|  Left |  Left |
|  Enter |  Ok |
|  O)))/Audio |  Dual |
|  [...] /Subtitle |  Subt |
|  Zoom |  Shift + Eject |





| Originale | | Sostituto | |
|-----------|-----------|-----------|---------------|
| | Clear | | Exit |
| | Rec | | Rec |
| | Rec Mode | + | Shift + Rec |
| | Thumbnail | | Text |
| | Timer Rec | + | Shift + AV |
| | CHP.ADD | | Format |
| | A-B | | 3D |
| | TV-VCR | | TV/R |
| | Play Mode | + | Shift + Play |
| | Marker | | Smart |
| | Search | + | Shift + TV/R |
| | Power Tv | + | Shift + Power |
| | AV Tv | | Media |
| | PR+ Tv | | Ch + |
| | PR- Tv | | Ch - |
| | Vol+ Tv | | Vol + |
| | Vol- Tv | | Vol - |

| Originale | Sostituto |
|-----------|-----------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

