



Originale	Sostituto
 Power	 Power
 Open / Close	 Eject
 TV / DVD	 TV/R
 PIP	 3D
 AV	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Title	 Smart
 Instant Skip	 Media

Originale	Sostituto
 TV Power	 Shift + Power
 TV AV	 Shift + AV
 TV PR +	 Ch +
 TV PR -	 Ch -
 TV Vol +	 Vol +
 TV Vol -	 Vol -
 << Scan	 <<
 >> Scan	 >>
 I<< Skip	 I<<
 >>I Skip	 >>I
 Pause / Step	 Pause
 Play	 Play
 Stop	 Stop
 Menu / List	 Menu
 Menu / List	 List
 Setup	 Options
 Up / PR +	 Up



