








































| Originale   | Sostituto  |
|---|--|
|  Power     |  Power              |
|  TV/RAD    |  TV/Radio /         |
|  Q.Menu    |  D.Menu / Top       |
|  Subtitle  |  Subtitle / EQ      |
|  Guide     |  Guide / EPG / -/-- |
|  [ ]/Ratio |  Picture / Format   |
|  Input     |  AV / Input / RDS   |
|  1         |  1                  |
|  2         |  2                  |
|  3         |  3                  |
|  4        |  4                 |
|  5       |  5                |
|  6       |  6                |
|  7       |  7                |
|  8       |  8                |
|  9       |  9                |
|  0       |  0                |

| Originale   | Sostituto   |
|---|---|
|  List      |  Shift + Smart / List    |
|  Q.View    |  Display / Media         |
|  Vol+      |  Vol+                    |
|  Vol-      |  Vol-                    |
|  Mute      |  Mute / Dimmer           |
|  FAV       |  Fav / Marker / PC       |
|  P+        |  CH+ / Page+             |
|  APP/*     |  Audio / Lang I/II       |
|  P-        |  CH- / Page-             |
|  [≡]/Text  |  Text / Goto             |
|  Info     |  Info / Angle           |
|  Smart   |  Smart / List          |
|  My APPS |  Sound / Title         |
|  Back    |  Back / Return         |
|  Exit    |  Exit / Cancel / Clear |
|  T.OPT   |  Setup / OPT /         |
|  Up      |  Up                    |



