



Originale	Sostituto
 TV/RAD	 TV/Radio /
 Power	 Power
 Input	 AV / Input / RDS
 AV Mode	 Picture / Format
 Power Saving	 Eject / Surround
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 List	 Smart / List
 0	 0
 Q.View	 Display / Media

Originale	Sostituto
 Vol+	 Vol+
 Mute	 Mute / Dimmer
 P+/Page Up	 CH+ / Page+
 Vol-	 Vol-
 P-/Page Down	 CH- / Page-
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Menu	 Menu / Home
 Down	 Down
 Return / Exit	 Back / Return
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 Text/[≡]	 Text / Goto





Originale	Sostituto
T.OPT	Setup / OPT /
Subtitle	Subtitle / EQ
FAV	Fav / Marker / PC
Q.Menu	D.Menu / Top
Info	Info / Angle
Guide	Guide / EPG / -/--

Originale	Sostituto

