











































































| Originale  | Sostituto  |
|--|--|
|  Power              |  Power                  |
|  1                  |  1                      |
|  2                  |  2                      |
|  3                  |  3                      |
|  4                  |  4                      |
|  5                  |  5                      |
|  6                  |  6                      |
|  7                  |  7                      |
|  8                  |  8                      |
|  9                  |  9                      |
|  0                 |  0                     |
|  AV/CL            |  AV / Input / RDS     |
|  Zoom             |  Zoom / Size          |
|  [...] / Subtitle |  Subtitle / EQ        |
|  Audio / Language |  Audio / Lang I / II  |
|  ◀ / Camera       |  Shift + Info / Angle |
|  ?                |  Setup / OPT /        |











| Originale  | Sostituto  |
|--|--|
|  ECO              |  Display / Media      |
|  CEC              |  Smart / List         |
|  Mute             |  Mute / Dimmer        |
|  i                |  Info / Angle         |
|  Z / Back         |  Back / Return        |
|  PR+              |  CH+ / Page+          |
|  Up               |  Up                   |
|  Vol-             |  Vol-                 |
|  Left             |  Left                 |
|  OK               |  OK                   |
|  Right           |  Right               |
|  Vol+           |  Vol+               |
|  Down           |  Down               |
|  PR-            |  CH- / Page-        |
|  TVG / Top Menu |  Guide / EPG / -/-- |
|  TVG / Top Menu |  D.Menu / Top       |
|  TXT / Menu     |  Text / Goto        |







| Originale  | Sostituto  |
|--|--|
|  Power              |  Power                  |
|  1                  |  1                      |
|  2                  |  2                      |
|  3                  |  3                      |
|  4                  |  4                      |
|  5                  |  5                      |
|  6                  |  6                      |
|  7                  |  7                      |
|  8                  |  8                      |
|  9                  |  9                      |
|  0                 |  0                     |
|  AV/CL            |  AV / Input / RDS     |
|  Zoom             |  Zoom / Size          |
|  [...] / Subtitle |  Subtitle / EQ        |
|  Audio / Language |  Audio / Lang I/II    |
|  ◀ / Camera       |  Shift + Info / Angle |
|  ?                |  Setup / OPT /        |

| Originale  | Sostituto  |
|--|--|
|  ECO              |  Display / Media      |
|  CEC              |  Smart / List         |
|  Mute             |  Mute / Dimmer        |
|  i                |  Info / Angle         |
|  Z / Back         |  Back / Return        |
|  PR+              |  CH+ / Page+          |
|  Up               |  Up                   |
|  Vol-             |  Vol-                 |
|  Left             |  Left                 |
|  OK               |  OK                   |
|  Right           |  Right               |
|  Vol+           |  Vol+               |
|  Down           |  Down               |
|  PR-            |  CH- / Page-        |
|  TVG / Top Menu |  Guide / EPG / -/-- |
|  TVG / Top Menu |  D.Menu / Top       |
|  TXT / Menu     |  Menu / Home        |









































| Originale | Sostituto            |
|-----------|----------------------|
|           | Power                |
|           | 1                    |
|           | 2                    |
|           | 3                    |
|           | 4                    |
|           | 5                    |
|           | 6                    |
|           | 7                    |
|           | 8                    |
|           | 9                    |
|           | 0                    |
|           | AV / Input / RDS     |
|           | Zoom / Size          |
|           | Subtitle / EQ        |
|           | Audio / Lang I/II    |
|           | Shift + Info / Angle |
|           | Setup / OPT /        |






























| Originale | Sostituto          |
|-----------|--------------------|
|           | Display / Media    |
|           | Smart / List       |
|           | Mute / Dimmer      |
|           | Info / Angle       |
|           | Back / Return      |
|           | CH+ / Page+        |
|           | Up                 |
|           | Vol-               |
|           | Left               |
|           | OK                 |
|           | Right              |
|           | Vol+               |
|           | Down               |
|           | CH- / Page-        |
|           | Guide / EPG / -/-- |
|           | D.Menu / Top       |
|           | Text / Goto        |







| Originale  | Sostituto   |
|--|---|
|  Power              |  Power                   |
|  1                  |  1                       |
|  2                  |  2                       |
|  3                  |  3                       |
|  4                  |  4                       |
|  5                  |  5                       |
|  6                  |  6                       |
|  7                  |  7                       |
|  8                  |  8                       |
|  9                  |  9                       |
|  0                 |  0                      |
|  AV/CL            |  AV / Input / RDS      |
|  Zoom             |  Zoom / Size           |
|  [...] / Subtitle |  Subtitle / EQ         |
|  Audio / Language |  Audio / Lang I / II   |
|  ◀ / Camera       |  Shift + Info / Angle |
|  ?                |  Setup / OPT /         |

| Originale  | Sostituto  |
|--|--|
|  ECO              |  Display / Media      |
|  CEC              |  Smart / List         |
|  Mute             |  Mute / Dimmer        |
|  i                |  Info / Angle         |
|  Z / Back         |  Back / Return        |
|  PR+              |  CH+ / Page+          |
|  Up               |  Up                   |
|  Vol-             |  Vol-                 |
|  Left             |  Left                 |
|  OK               |  OK                   |
|  Right           |  Right               |
|  Vol+           |  Vol+               |
|  Down           |  Down               |
|  PR-            |  CH- / Page-        |
|  TVG / Top Menu |  Guide / EPG / -/-- |
|  TVG / Top Menu |  D.Menu / Top       |
|  TXT / Menu     |  Text / Goto        |



