










































































| Originale  | Sostituto  |
|--|--|
|  Power  |  Power            |
|  1      |  1                |
|  2      |  2                |
|  3      |  3                |
|  PIP    |  Info / Angle     |
|  4      |  4                |
|  5      |  5                |
|  6      |  6                |
|  [ <> ] |  Picture / Format |
|  >     |  >>  / Preset+   |
|  7    |  7              |
|  8    |  8              |
|  9    |  9              |
|  ?    |  Smart / List   |
|   <   |   << / Preset-  |
|  0    |  0              |
|  Mute |  Mute / Dimmer  |

| Originale  | Sostituto  |
|--|--|
|  i/OSD          |  Display / Media          |
|  Z/Disc Menu    |  Menu / Home              |
|  Up             |  Up                       |
|  P+             |  CH+ / Page+              |
|  Left           |  Left                     |
|  Vol-           |  Vol-                     |
|  OK             |  OK                       |
|  Right          |  Right                    |
|  Vol+           |  Vol+                     |
|  TXT           |  Text / Goto             |
|  <<           |  << / Tune-             |
|  Down         |  Down                   |
|  P-           |  CH- / Page-            |
|  TV-G         |  Guide / EPG / -/-      |
|  >>           |  >> / Tune+             |
|  Red/Image/I> |  Red / Netflix / Search |
|  Green/Timer  |  Green / APP / Repeat   |








































































|  | Originale   | Sostituto   | Originale | Sostituto |
|--|---|---|-----------|-----------|
|  |  |  Play / Slow                 |           |           |
|  |  |  Yellow / YouTube / Repeat   |           |           |
|  |  |  Pause / Step / Freeze       |           |           |
|  |  |  Blue / Prime Video / Random |           |           |
|  |  |  Stop / Hold                 |           |           |
|  |  |  Sound / Title               |           |           |
|  |   |   |           |           |
|  |   |   |           |           |
|  |   |   |           |           |
|  |   |   |           |           |
|  |   |   |           |           |
|  |   |   |           |           |
|  |   |   |           |           |
|  |   |   |           |           |
|  |   |   |           |           |
|  |   |   |           |           |
|  |   |   |           |           |
|  |   |   |           |           |
|  |   |   |           |           |
|  |   |   |           |           |
|  |   |   |           |           |
|  |   |   |           |           |
|  |   |   |           |           |
|  |   |   |           |           |
|  |   |   |           |           |
|  |   |   |           |           |
|  |   |   |           |           |
|  |   |   |           |           |





| Originale   | Sostituto   |
|---|---|
|  Power   |  Power             |
|  1       |  1                 |
|  2       |  2                 |
|  3       |  3                 |
|  Audio   |  Audio / Lang I/II |
|  4       |  4                 |
|  5       |  5                 |
|  6       |  6                 |
|  [ <> ]  |  Zoom / Size       |
|  >       |  >>  / Preset+     |
|  7       |  7                 |
|  8     |  8               |
|  9     |  9               |
|  ?     |  Smart / List    |
|   <    |   << / Preset-   |
|  0     |  0               |
|  i/OSD |  Display / Media |

| Originale   | Sostituto  |
|---|--|
|  Disc Menu     |  D.Menu / Top             |
|  Disc Menu     |  Menu / Home              |
|  Up            |  Up                       |
|  P+            |  CH+ / Page+              |
|  Left          |  Left                     |
|  Vol-          |  Vol-                     |
|  OK            |  OK                       |
|  Right         |  Right                    |
|  Vol+          |  Vol+                     |
|  TXT           |  Text / Goto              |
|  <<            |  << / Tune-               |
|  Down        |  Down                   |
|  P-          |  CH- / Page-            |
|  TV-G        |  Guide / EPG / -/-      |
|  >>          |  >> / Tune+             |
|  Red/Picture |  Picture / Format       |
|  Red/Picture |  Red / Netflix / Search |







































































| Originale | Sostituto                   | Originale | Sostituto |
|-----------|-----------------------------|-----------|-----------|
|           | Sleep / Timer               |           |           |
|           | Play / Slow                 |           |           |
|           | Green / APP / Repeat        |           |           |
|           | Yellow / YouTube / Repeat   |           |           |
|           | Pause / Step / Freeze       |           |           |
|           | Sound / Title               |           |           |
|           | Stop / Hold                 |           |           |
|           | Blue / Prime Video / Random |           |           |
|           |                             |           |           |
|           |                             |           |           |
|           |                             |           |           |
|           |                             |           |           |
|           |                             |           |           |
|           |                             |           |           |
|           |                             |           |           |
|           |                             |           |           |
|           |                             |           |           |
|           |                             |           |           |
|           |                             |           |           |
|           |                             |           |           |
|           |                             |           |           |
|           |                             |           |           |
|           |                             |           |           |
|           |                             |           |           |
|           |                             |           |           |
|           |                             |           |           |
|           |                             |           |           |
|           |                             |           |           |





| Originale  | Sostituto   |
|--|---|
|  Power  |  Power             |
|  1      |  1                 |
|  2      |  2                 |
|  3      |  3                 |
|  Audio  |  Audio / Lang I/II |
|  4      |  4                 |
|  5      |  5                 |
|  6      |  6                 |
|  [ <> ] |  Zoom / Size       |
|  >     |  >>  / Preset+    |
|  7    |  7               |
|  8    |  8               |
|  9    |  9               |
|  ?    |  Smart / List    |
|   <   |   << / Preset-   |
|  0    |  0               |
|  Mute |  Mute / Dimmer   |

| Originale  | Sostituto  |
|--|--|
|  i/OSD              |  Display / Media          |
|  Z/Disc Menu        |  Menu / Home              |
|  Up                 |  Up                       |
|  P+                 |  CH+ / Page+              |
|  Left               |  Left                     |
|  Vol-               |  Vol-                     |
|  OK                 |  OK                       |
|  Right              |  Right                    |
|  Vol+               |  Vol+                     |
|  TXT               |  Text / Goto             |
|  <<               |  << / Tune-             |
|  Down             |  Down                   |
|  P-               |  CH- / Page-            |
|  TV-G             |  Guide / EPG / -/-      |
|  >>               |  >> / Tune+             |
|  Red / Image / I> |  Red / Netflix / Search |
|  Red / Image / I> |  Shift + Play / Slow    |







| Originale | Sostituto         |
|-----------|-------------------|
| Power     | Power             |
| 1         | 1                 |
| 2         | 2                 |
| 3         | 3                 |
| PIP/Audio | Audio / Lang I/II |
| 4         | 4                 |
| 5         | 5                 |
| 6         | 6                 |
| [ <> ]    | Zoom / Size       |
| 7         | 7                 |
| 8         | 8                 |
| 9         | 9                 |
| ?         | Smart / List      |
| I<        | I<< / Preset-     |
| >I        | >>I / Preset+     |
| 0         | 0                 |
| i/OSD     | Display / Media   |

| Originale    | Sostituto              |
|--------------|------------------------|
| Z/Disc Menu  | Menu / Home            |
| P+           | CH+ / Page+            |
| Up           | Up                     |
| Left         | Left                   |
| Vol-         | Vol-                   |
| OK           | OK                     |
| Right        | Right                  |
| Vol+         | Vol+                   |
| TXT          | Text / Goto            |
| <<           | << / Tune-             |
| P-           | CH- / Page-            |
| Down         | Down                   |
| TV-G         | Guide / EPG / -/-      |
| >>           | >> / Tune+             |
| Red/Image/I> | Picture / Format       |
| Red/Image/I> | Red / Netflix / Search |
| Green/Timer  | Green / APP / Repeat   |



