

















































































































































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 CH+	 CH+ / Page+
 Aspect	 Picture / Format	 Vol-	 Vol-
 Mute	 Mute / Dimmer	 Audio	 Audio / Lang I/II
 1	 1	 CH-	 CH- / Page-
 2	 2	 i	 Info / Angle
 3	 3	 GUIDE	 Guide / EPG / -/-
 4	 4	 Rec	 Rec / Rec Mode
 5	 5	 MENU	 Menu / Home
 6	 6	 Up	 Up
 7	 7	 Input	 AV / Input / RDS
 8	 8	 Left	 Left
 9	 9	 OK	 OK
 List	 Smart / List	 Right	 Right
 0	 0	 BACK	 Back / Return
 Repeat	 Green / APP / Repeat	 Down	 Down
 Vol+	 Vol+	 Exit / DVD Setup	 Exit / Cancel / Clear
 S	 Subtitle / EQ	 Exit / DVD Setup	 Shift + Exit / Cancel / Clear

Originale	Sostituto	Originale	Sostituto
 Power	 Power	 TV	 TV
 Aspect	 Picture / Format	 DVD	 DVD
 Mute	 Mute / Dimmer	 SAT	 SAT
 1	 1	 AUX	 AUX
 2	 2	 SLOW	 SLOW
 3	 3	 STEP-FREEZE	 STEP-FREEZE
 4	 4	 HOLD	 HOLD
 5	 5	 REC MODE	 REC MODE
 6	 6	 TUNE-	 TUNE-
 7	 7	 TUNE+	 TUNE+
 8	 8	 PRESET-	 PRESET-
 9	 9	 PRESET+	 PRESET+
 List	 List	 TITLE	 TITLE
 0	 0	 LANG I/II	 LANG I/II
 Repeat	 Repeat	 EQ	 EQ
 Vol+	 Vol+	 SURROUND	 SURROUND
 S	 S	 SOUND	 SOUND
		 AUDIO	 AUDIO
		 SUBTITLE	 SUBTITLE
		 TIMER	 TIMER
		 PROGRAM	 PROGRAM
		 TV RADIO	 TV RADIO
		 RDS	 RDS
		 AV INPUT	 AV INPUT
		 HOME	 HOME
		 ANGLE	 ANGLE
		 MENU	 MENU
		 INFO	 INFO
		 OK	 OK
		 RETURN	 RETURN
		 BACK	 BACK
		 EXIT	 EXIT
		 CANCEL	 CANCEL
		 LIST	 LIST
		 SMART	 SMART
		 MEDIA	 MEDIA
		 DISPLAY	 DISPLAY
		 CH PAGE	 CH PAGE
		 TV	 TV
		 DVD	 DVD
		 CD-8TB	 CD-8TB
		 VIDEO	 VIDEO
		 TAPE	 TAPE
		 TUNER	 TUNER
		 AUX-HDD	 AUX-HDD
		 USB	 USB
		 BLUETOOTH	 BLUETOOTH
		 7	 7
		 8	 8
		 9	 9
		 HDMI-BAT	 HDMI-BAT
		 FC	 FC
		 GUIDE EPG	 GUIDE EPG
		 0	 0
		 FAV MARKER	 FAV MARKER
		 NETFLIX	 NETFLIX
		 APP	 APP
		 YouTube	 YouTube
		 Prime Video	 Prime Video
		 SEARCH	 SEARCH
		 REPEAT	 REPEAT
		 REPEAT A-B	 REPEAT A-B
		 RANDOM	 RANDOM
		 Mandis SHOP	 Mandis SHOP
		 www.mandis.tv	 www.mandis.tv





Originale	Sostituto
Red / Prog	Red / Netflix / Search
Red / Prog	Shift + Red / Netflix / Search
Green / Step	Shift + Green / APP / Repeat
Yellow / Goto	Yellow / YouTube / Repeat
Blue / A-B	Blue / Prime Video / Random
Index / Stop	Pause / Step / Freeze
Hold / Play/Pause	Shift + Stop /
Hold / Play/Pause	Stop / Hold
Reveal / <<	<< / Tune-
Size / >>	>> / Tune+
FAV / Menu	Fav / Marker / PC
FAV / Menu	Shift + Fav / Marker / PC
TV.RD / Angle	TV/Radio /
Mix / I<<	I<< / Preset-
S.Page / >>I	Shift + >>I / Preset+
S.Page / >>I	>>I / Preset+
Title	Sound / Title

Originale	Sostituto
Slow	Play / Slow
Text / Zoom	Shift + Text /
Text / Zoom	Text / Goto
Cancel /	Shift + Eject / Surround
Cancel /	Eject / Surround

