




Originale	Sostituto
 Power	 Power
 Mute	 Mute
 TV	 Smart
 Tv/Rad	 TV/R
 Audio	 Dual
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Text	 Text
 SUB	 Subt

Originale	Sostituto
 EPG	 Guide
 Menu	 Menu
 Exit	 Exit
 ALT	 Pre Ch
 Up/Channel+	 Up
 Down/Channel-	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Vol+	 Vol +
 Vol-	 Vol -
 Freeze	 Pause
 Browse	 Media
 Page+	 Ch +
 Page-	 Ch -
 Red	 Red
 Green	 Green





Originale		Sostituto		Originale		Sostituto	
	Yellow		Yellow				
	Blue		Blue				
	White/Info		Info				

