































































































































































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Menu	 Menu
 Source	 AV	 Guide	 Guide
 P.Mode	 Format	 Up	 Up
 S.Mode	 Dual	 Left	 Left
 Home	 Shift + Smart	 OK	 Ok
 1	 1	 Right	 Right
 2	 2	 Down	 Down
 3	 3	 Back	 Back
 4	 4	 Exit	 Exit
 5	 5	 Vol +	 Vol +
 6	 6	 Vol -	 Vol -
 7	 7	 APP Store	 Media
 8	 8	 Mute	 Mute
 9	 9	 Tool	 Options
 0	 0	 CH +	 Ch +
 Q.View	 D. Menu	 CH -	 Ch -
 Info	 Info	 FAV	 Pre Ch

Originale	Sostituto	Originale	Sostituto
 Power	 Power	 TV	 DVD
 Source	 Source	 SAT	 AUX
 P.Mode	 P.Mode	 PLAY MODE	 REC MODE
 S.Mode	 S.Mode	 TV	 TV
 Home	 Home	 DUAL	 SUBT
 1	 1	 AD	 SETTINGS
 2	 2	 LIST	 OPT
 3	 3	 SEARCH	 ECO
 4	 4	 PICTURE	 3D
 5	 5	 SLEEP	 TIMER
 6	 6	 TV/R	 AV
 7	 7	 FORMAT	 AV
 8	 8	 E-MANUAL	 E-MANUAL
 9	 9	 REPEAT	 REPEAT
 0	 0	 ZOOM	 ZOOM
Q.VIEW	Q.VIEW	 TEXT	 TEXT
INFO	INFO	 UP	 UP
MUTE	MUTE	 DOWN	 DOWN
SHIFT	SHIFT	 RETURN	 RETURN
TV	TV	 CLEAR	 CLEAR
DVD	DVD	 EXIT	 EXIT
SAT	SAT	 HOME	 HOME
AUX	AUX	 SMART	 SMART
PLAY MODE	PLAY MODE	 APP	 APP
REC MODE	REC MODE	 MEDIA	 MEDIA
TV	TV	 CH +	 CH +
DVD	DVD	 VOL +	 VOL +
SAT	SAT	 VOL -	 VOL -
AUX	AUX	 CH -	 CH -
PLAY MODE	PLAY MODE	 1	 1
REC MODE	REC MODE	 2	 2
TV	TV	 3	 3
DVD	DVD	 4	 4
SAT	SAT	 5	 5
AUX	AUX	 6	 6
PLAY MODE	PLAY MODE	 7	 7
REC MODE	REC MODE	 8	 8
TV	TV	 9	 9
DVD	DVD	 0	 0
SAT	SAT	 GUIDE	 GUIDE
AUX	AUX	 PRE-CH	 PRE-CH
PLAY MODE	PLAY MODE	 A	 A
REC MODE	REC MODE	 B	 B
TV	TV	 C	 C
DVD	DVD	 D	 D
SAT	SAT	 Mandis SHOP	 Mandis SHOP
AUX	AUX	www.mandis.tv	www.mandis.tv





Originale		Sostituto		Originale		Sostituto	
	APP		Smart				
	CH. List		List				
	<<		<<				
	Play		Play				
	>>		>>				
	Stop		Stop				
	Pause		Pause				
	Rec		Rec				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				

