








































Originale	Sostituto
 Power	 Power
 Source	 AV
 P.Mode	 Format
 S.Mode	 Shift + Dual
 Home	 Smart
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Q.View	 Options
 Sleep	 Sleep

Originale	Sostituto
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 I/II/Audio	 Dual
 P+	 Ch +
 P-	 Ch -
 Subtitle	 Subt
 3D World	 3D
 Info	 Info
 FAV	 Pre Ch
 Screen	 Media
 CH List	 List
 Menu	 Menu
 Guide	 Guide
 Back	 Back
 Exit	 Exit
 Up	 Up





Originale		Sostituto		Originale		Sostituto	
	Down		Down				
	Right		Right				
	Left		Left				
	OK		Ok				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	<<		<<				
	>>		>>				
	I<<		I<<				
	>>I		>>I				
	Text		Text				
	Play		Play				
	Pause		Pause				
	Stop		Stop				
	Rec		Rec				

