


























































Originale	Sostituto
 Power	 Power
 Input	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Guide	 Guide
 Subtitle	 Subt
 Red	 Red
 Green	 Green
 Yellow	 Yellow

Originale	Sostituto
 Blue	 Blue
 [≡]	 Menu
 TXT	 Text
 Back	 Back
 Home	 Smart
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 CH.List	 List
 CH+	 Ch +
 CH-	 Ch -





Originale		Sostituto		Originale		Sostituto	
	<<		<<				
	Play		Play				
	>>		>>				
	Pause		Pause				
	AudioOnly		Dual				
	Stop		Stop				
	Prime Video		Media				
	You Tube		Shift + Media				
	Netflix		Shift + Smart				
	Rakuten Tv		TV/R				

