










































Originale	Sostituto
 Power	 Power
 O/D/N	 D.Menu / Top
 Sound / Title	 Sound / Title
 Shift + Back / Return	 Shift + Back / Return
 Source	 AV / Input / RDS
 Info / Angle	 Info / Angle
 Audio / Lang I/II	 Audio / Lang I/II
 Shift + Text / Goto	 Shift + Text / Goto
 Red / Netflix / Search	 Red / Netflix / Search
 Text / Goto	 Text / Goto
 Green / APP / Repeat	 Green / APP / Repeat
 Yellow / YouTube / Repeat	 Yellow / YouTube / Repeat
 Blue / Prime Video / Random	 Blue / Prime Video / Random
 Menu / Home	 Menu / Home
 Back / Return	 Back / Return
 CH+ / Page+	 CH+ / Page+
 Up	 Up

Originale	Sostituto
 Right	 Right
 Vol+	 Vol+
 Left	 Left
 Vol-	 Vol-
 OK	 OK
 CH- / Page-	 CH- / Page-
 Down	 Down
 Power DVD	 Shift + Power
 Play / Slow	 Play / Slow
 Mute / Dimmer	 Mute / Dimmer
 << / Tune-	 << / Tune-
 Pause / Step / Freeze	 Pause / Step / Freeze
 >> / Tune+	 >> / Tune+
 Shift + Pause / Step / Freeze	 Shift + Pause / Step / Freeze
 I<< / Preset-	 I<< / Preset-
 Stop / Hold	 Stop / Hold
 >>I / Preset+	 >>I / Preset+





Originale	Sostituto
ZOOM [<>]/Zoom	SIZE ZOOM Zoom / Size
1 1	1 1
2 2	2 2
3 3	3 3
4 4	4 4
5 5	5 5
6 6	6 6
7 7	7 7
8 8	8 8
9 9	9 9
▼	SHIFT + [Up Arrow] Shift + Up
0 0	0 0
▲	SHIFT + [Down Arrow] Shift + Down
AV1	SHIFT + TV 1 Shift + 1
AV2	SHIFT + DVD 2 Shift + 2
AV3	SHIFT + CD - STB 3 Shift + 3
AV4	SHIFT + VIDEO 4 Shift + 4

Originale	Sostituto
Timer	TIMER SLEEP Sleep / Timer
RGB1	LIST SMART Smart / List
RGB2	MEDIA DISPLAY Display / Media

