

















































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Vol-		Vol -
	[i+]		Info		Mute		Mute
	[1]2 Dual Screen		Smart		P+		Ch +
	Red / Demo		Red		P-		Ch -
	Green		Green		1		1
	Yellow		Yellow		2		2
	Blue		Blue		3		3
	Option		Options		4		4
	Guide		Guide		5		5
	Up		Up		6		6
	Left		Left		7		7
	OK		Ok		8		8
	Right		Right		9		9
	Down		Down		0		0
	Menu / Browse		Menu		AV		AV
	Text		Text		P<P		Back
	Vol+		Vol +		<<		<<





Originale	Sostituto	Originale	Sostituto
 Stop / MHEG	 Stop		
 Play	 Play		
 >>	 >>		
 Rec	 Rec		
 FAV	 Pre Ch		

