







































































Originale	Sostituto	Originale	Sostituto
	Power		Power
	Mute		Mute
	Tv/Radio		TV/R
	Sub		Subt
	Audio		Dual
	Text		Text
	Wide		Format
	List		List
	Rec		Rec
	<<		<<
	Pause		Pause
	Play		Play
	>>		>>
	Stop		Stop
	↻		I<<
	→		>>
	Media		Media
	Guide		Guide
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	Exit		Exit
	Back		Back
	Vol+		Vol +
	Vol-		Vol -
	i		Info
	OPT+		Options
	P+		Ch +
	P-		Ch -
	Red		Red
	Green		Green
	Yellow		Yellow



