


























Originale	Sostituto	Originale	Sostituto
	Power		Power
	Mute		Mute
	Source		AV
	Sleep		Sleep
	V-Format		Format
	Wide		Eject
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Text		Text

Originale	Sostituto	Originale	Sostituto
	Menu		Menu
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	List		List
	Guide		Guide
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	Exit		Exit
	Back		Back
	Vol+		Vol +
	Vol-		Vol -
	i		Info





Originale		Sostituto		Originale		Sostituto	
	OPT+		Options				
	P+		Ch +				
	P-		Ch -				
	Schedule		Smart				
	Audio		Dual				
	Sub		Subt				
	Tv/Radio		TV/R				

