







































































































Originale	Sostituto	Originale	Sostituto
On/Off	 Power	OK Enter	 Ok
Audio Off	 Mute	Menu Right	 Right
Slow Up	 Ch +	Menu Down	 Down
Stop	 Stop	Next	 >>
Slow Down	 Ch -	Return	 Back
Pause	 Pause	Top Menu	 D. Menu
Subt.	 Subt	Progr.	 Sleep
Auto/Track	 Smart	Prev.	 <<
Title	 List	Volume+	 Vol +
Rep/A-B	 TV/R	Volume-	 Vol -
Repeat/1/All	 Text	1	 1
Zoom	 Eject	2	 2
DVD/TV	 AV	3	 3
Menu	 Menu	4	 4
Menu Up	 Up	5	 5
Display	 Info	6	 6
Menu Left	 Left	7	 7





































Originale	Sostituto	Originale	Sostituto
On/Off	 Power	OK Enter	 Ok
Audio Off	 Mute	Menu Right	 Right
Slow Up	 Ch +	Menu Down	 Down
Stop	 Stop	Progr.	 Sleep
Pause	 Pause	Return	 Back
Slow Down	 Ch -	Volume+	 Vol +
Subt.	 Subt	Next	 >>
Auto/Track	 Smart	Volume-	 Vol -
Rep/A-B	 TV/R	1	 1
Repeat/1/All	 Text	Top Menu	 D. Menu
Zoom	 Eject	Prev.	 <<
DVD/TV	 AV	2	 2
Title	 List	3	 3
Menu	 Menu	4	 4
Menu Up	 Up	5	 5
Display	 Info	6	 6
Menu Left	 Left	7	 7



Originale	Sostituto	Originale	Sostituto
On/Off	 Power	Progr.	 Sleep
Menu Down	 Down	Display	 Info
Audio Off	 Mute	Menu Left	 Left
Slow Down	 Ch -	OK Enter	 Ok
Stop	 Stop	Menu Right	 Right
Slow Up	 Ch +	Volume+	 Vol +
Pause	 Pause	Volume-	 Vol -
Subt.	 Subt	1	 1
Rep/A-B	 TV/R	2	 2
Repeat/1/All	 Text	3	 3
Zoom	 Eject	4	 4
Auto/Track	 Smart	Next	 >>
DVD/TV	 AV	5	 5
Title	 List	Top Menu	 D. Menu
Menu	 Menu	6	 6
Return	 Back	Prev.	 <<
Menu Up	 Up	7	 7



Originale	Sostituto	Originale	Sostituto
On/Off	 Power	Progr.	 Sleep
Audio Off	 Mute	Menu Left	 Left
Stop	 Stop	Next	 >>
Slow Up	 Ch +	OK Enter	 Ok
Auto/Track	 Smart	Top Menu	 D. Menu
Slow Down	 Ch -	Prev.	 I<<
Pause	 Pause	Menu Right	 Right
Title	 List	Menu Down	 Down
Subt.	 Subt	Volume+	 Vol +
Rep/A-B	 TV/R	Volume-	 Vol -
Repeat/1/All	 Text	1	 1
Zoom	 Eject	2	 2
DVD/TV	 AV	3	 3
Menu	 Menu	4	 4
Menu Up	 Up	5	 5
Return	 Back	6	 6
Display	 Info	7	 7



