







































































| Originale   |           | Sostituto   |         | Originale   |       | Sostituto   |         |
|---|-----------|---|---------|---|-------|---|---------|
|    | POWER     |    | Power   |    | 0     |    | 0       |
|    | DVD / USB |    | 3D      |    | INFO  |    | Info    |
|    | HDMI      |    | Format  |    | SURR  |    | Back    |
|    | TV        |    | TV/R    |    | SETUP |    | D. Menu |
|    | LOAD      |    | Options |    | SOUND |    | Dual    |
|    | AUDIO     |    | AV      |    | MENU  |    | Menu    |
|    | VIDEO     |    | Eject   |    | UP    |    | Up      |
|    | RADIO     |    | Text    |    | RIGHT |    | Right   |
|    | 1         |    | 1       |    | DOWN  |    | Down    |
|    | 2         |    | 2       |    | LEFT  |    | Left    |
|  | 3         |  | 3       |  | OK    |  | Ok      |
|  | 4         |  | 4       |  | VOL - |  | Vol -   |
|  | 5         |  | 5       |  | VOL + |  | Vol +   |
|  | 6         |  | 6       |  | MUTE  |  | Mute    |
|  | 7         |  | 7       |  | I<<   |  | I<<     |
|  | 8         |  | 8       |  | >>I   |  | >>I     |
|  | 9         |  | 9       |  | STOP  |  | Stop    |





| Originale   | Sostituto | Originale   | Sostituto |
|---|-----------|---|-----------|
|  | <<        |  | <<        |
|  | >>        |  | >>        |
|  | PLAY      |  | Play      |
|  | PAUSE     |  | Pause     |
|  | SHUFF     |  | Smart     |
|  | SUB-T     |  | Subt      |
|  | LANG      |  | Media     |
|   |           |   |           |
|   |           |   |           |
|   |           |   |           |
|   |           |   |           |
|   |           |   |           |
|   |           |   |           |
|   |           |   |           |
|   |           |   |           |
|   |           |   |           |
|   |           |   |           |
|   |           |   |           |
|   |           |   |           |
|   |           |   |           |
|   |           |   |           |
|   |           |   |           |
|   |           |   |           |
|   |           |   |           |

