



Originale	Sostituto	Originale	Sostituto
	Power		Power
	Mute		Mute / Dimmer
	Play		Play / Slow
	Pause		Pause / Step / Freeze
	I<		I<< / Preset-
	>I		>>I / Preset+
	Sound Mode		Sound / Title
	Surround		Eject / Surround
	Night Mode		Sleep / Timer
	Source		AV / Input / RDS
	Vol+		Vol+
	Audio Sync +		CH+ / Page+
	Vol-		Vol-
	DIM Display		Display / Media
	Audio Sync -		CH- / Page-
	Bluetooth		9
	Shuffle		Blue / Prime Video / Random

Originale	Sostituto	Originale	Sostituto
	Soundshift		Shift + Sound / Title
	Bass+		Shift + Vol+
	Bass-		Shift + Vol-

