



| Originale | | Sostituto | | Originale | | Sostituto | |
|-----------|--------|-----------|---------------------------|-----------|------------|-----------|-----------------------------|
| | Mute | | Mute / Dimmer | | Blue | | Blue / Prime Video / Random |
| | Power | | Power | | TV | | TV/Radio / |
| | 1 | | 1 | | Up | | Up |
| | 2 | | 2 | | Menu | | Menu / Home |
| | 3 | | 3 | | Left | | Left |
| | 4 | | 4 | | OK | | OK |
| | 5 | | 5 | | Right | | Right |
| | 6 | | 6 | | [≡] / Text | | Text / Goto |
| | 7 | | 7 | | Down | | Down |
| | 8 | | 8 | | Back | | Back / Return |
| | 9 | | 9 | | P+ | | CH+ / Page+ |
| | i | | Info / Angle | | Vol + | | Vol+ |
| | 0 | | 0 | | P- | | CH- / Page- |
| | AV | | AV / Input / RDS | | Vol- | | Vol- |
| | Red | | Red / Netflix / Search | | ^ / Hold | | Shift + Stop / |
| | Green | | Green / APP / Repeat | | << / F.T/L | | << / Tune- |
| | Yellow | | Yellow / YouTube / Repeat | | Play / [?] | | Play / Slow |



