




































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Picture	 Format
 Mute	 Mute	 AV	 AV
 1	 1	 Menu	 Menu
 2	 2	 PR+	 Ch +
 3	 3	 Up	 Up
 4	 4	 PR-	 Ch -
 5	 5	 Down	 Down
 6	 6	 Right	 Right
 7	 7	 Vol+	 Vol +
 8	 8	 Vol-	 Vol -
 9	 9	 Left	 Left
 0	 0	 Up VCR	 Shift + Ch -
 Red/Zoom	 Red	 UP [≡]	 Shift + Text
 Green/00	 Green	 Up DVD	 Shift + Up
 Yellow	 Yellow	 Down VCR	 Shift + Ch +
 Blue	 Blue	 Down DVD	 Shift + Down
 Text	 Text	 << VCR	 Shift + <<

Originale	Sostituto	Originale	Sostituto
 Picture	 Format	 Picture	 Format
 AV	 AV	 AV	 AV
 Menu	 Menu	 Menu	 Menu
 PR+	 Ch +	 PR+	 Ch +
 Up	 Up	 Up	 Up
 PR-	 Ch -	 PR-	 Ch -
 Down	 Down	 Down	 Down
 Right	 Right	 Right	 Right
 Vol+	 Vol +	 Vol+	 Vol +
Vol-	Vol -	Vol-	Vol -
Left	Left	Left	Left
Up VCR	Shift + Ch -	Up VCR	Shift + Ch -
UP [≡]	Shift + Text	UP [≡]	Shift + Text
Up DVD	Shift + Up	Up DVD	Shift + Up
Down VCR	Shift + Ch +	Down VCR	Shift + Ch +
Down DVD	Shift + Down	Down DVD	Shift + Down
<< VCR	Shift + <<	<< VCR	Shift + <<



