

























































Originale	Sostituto	Originale	Sostituto
 Standby	 Power	 Picture	 Format
 Source	 AV	 DVD Setup / DVB Menu	 D. Menu
 1	 1	 CH +	 Ch +
 2	 2	 CH -	 Ch -
 3	 3	 Up	 Up
 4	 4	 Right	 Right
 5	 5	 Down	 Down
 6	 6	 Left	 Left
 7	 7	 Enter	 Ok
 8	 8	 LCD Menu	 Menu
 9	 9	 Mute	 Mute
 0	 0	 Eject / Auto	 Shift + Exit
 ZZZ	 Shift + Power	 Play / Pause	 Play
 Recall	 Back	 Play / Pause	 Pause
 Vol +	 Vol +	 Play / Pause	 Shift + Pause
 Vol -	 Vol -	 Stop / Exit	 Stop
 Audio	 Shift + Subt	 Stop / Exit	 Exit

Originale	Sostituto	Originale	Sostituto
 Standby	 Power	 Picture	 Format
 Source	 AV	 DVD Setup / DVB Menu	 D. Menu
 1	 1	 CH +	 Ch +
 2	 2	 CH -	 Ch -
 3	 3	 Up	 Up
 4	 4	 Right	 Right
 5	 5	 Down	 Down
 6	 6	 Left	 Left
 7	 7	 Enter	 Ok
 8	 8	 LCD Menu	 Menu
 9	 9	 Mute	 Mute
 0	 0	 Eject / Auto	 Shift + Exit
 ZZZ	 Shift + Power	 Play / Pause	 Play
 Recall	 Back	 Play / Pause	 Pause
 Vol +	 Vol +	 Play / Pause	 Shift + Pause
 Vol -	 Vol -	 Stop / Exit	 Stop
 Audio	 Shift + Subt	 Stop / Exit	 Exit





Originale	Sostituto
<< / Text	<<
<< / Text	Text
>> / Hold / FAV	>>
>> / Hold / FAV	Pre Ch
I<< / [=i]	I<<
>>I / Size	>>I
Title / Lang	+ Shift + Dual
Go / Fav +	+ Shift + Up
Zoom / Fav -	+ Shift + Down
Zoom / Fav -	3D
Subtitle / [=o]	Subt
Menu / Guide	Guide
Angle / [=?]	+ Shift + Format
Menu / Guide	+ Shift + Menu
Info	Info
Red / Program	Red
Audio I-II	Dual

Originale	Sostituto
Green / Intro	Green
Yellow / Recall	Yellow
Blue / A-B	Blue

