







































































Originale		Sostituto		Originale		Sostituto	
	Standby		Power		P-		Ch -
	STB PWR		Shift + Power		Mute		Mute
	1		1		Micro/Q		Format
	2		2		Home/Recents		TV/R
	3		3		*		Menu
	4		4		Back/Exit		Back
	5		5		Guide		Guide
	6		6		Mouse Up		>>
	7		7		Mouse Down		<<
	8		8		OK		Ok
	9		9		Up		Up
	0/Quick Access		0		Down		Down
	List		List		Right		Right
	AD		Subt		Left		Left
	Vol+		Vol +		Netflix		Shift + Media
	Vol-		Vol -		Amazon		Media
	P+		Ch +		Source		AV





Originale	Sostituto
Text	Text
T.Opt/Magic Link	Options
Info	Info
Play	Play
Pause	Pause
Live	3D
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue

Originale	Sostituto

