





































| | Originale | Sostituto |
|---|-----------|---|
|  | Power |  Power |
|  | Tv/AV |  AV |
|  | 1 |  1 |
|  | 2 |  2 |
|  | 3 |  3 |
|  | 5 |  5 |
|  | 4 |  4 |
|  | 6 |  6 |
|  | 7 |  7 |
|  | 8 |  8 |
|  | 9 |  9 |
|  | 0 |  0 |
|  | Mute |  Mute |
|  | Q.View |  Options |
|  | List |  List |
|  | Menu |  Menu |
|  | OK |  Ok |

| | Originale | Sostituto |
|---|-----------|---|
|  | ARC |  Media |
|  | PR+ |  Ch + |
|  | Up |  Up |
|  | Down |  Down |
|  | PR- |  Ch - |
|  | Vol+ |  Vol + |
|  | Right |  Right |
|  | Left |  Left |
|  | Vol- |  Vol - |
|  | Play |  Play |
|  | Stop |  Stop |
|  | >>/FF |  I<< |
|  | <</REW |  << |
|  | Rec |  Rec |
|  | Pause |  Pause |
|  | Power |  Shift + Power |
|  | SP/LP |  TV/R |





| Originale | Sostituto |
|---------------|-----------------|
| CH- | Shift + Ch - |
| CH+ | Shift + Ch + |
| QSR Start | D. Menu |
| QSR Length | Dual |
| Text | Text |
| Turbo Picture | Subt |
| Turbo Sound | Shift + Dual |
| Eye/* | Guide |
| I-III/* | Red |
| PSM | Green |
| SSM | Yellow |
| Size | Format |
| Hold | 3D |
| Update | Blue |
| Index | Info |
| Time | Shift + AV |
| Mix | Shift + Options |

| Originale | Sostituto |
|-----------|--------------|
| Reveal | Back |
| Mode | Shift + TV/R |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

