







































Originale	Sostituto	Originale	Sostituto
Power		Power	
OK		Subtitle / EQ	
Up		Setup / OPT /	
Down		>>	
Right		>> / Tune+	
Left		Play / Slow	
Back / Return		AD / PIP	
Vol +		<<	
Vol -		<<< / Preset-	
Home / Smart		Rec / Rec Mode	
3D	 +  3	Pause / Step / Freeze	
Mute / Dimmer		Text / Goto	
P +		FAV / Marker / PC	
P -		Exit / Cancel / Clear	
Ratio / Picture / Format		Input / RDS	
List / Smart		Blue / Prime Video / Random	
Q.Menu / D.Menu / Top		Yellow / YouTube / Repeat	
		Stop / Live TV	



Originale	Sostituto	Originale	Sostituto
AV Mode	 +  Shift + AV / Input / RDS	5	 5
Green	 Green / APP / Repeat	Q.View	 +  Shift + Display / Media
Red	 Red / Netflix / Search	4	 4
0	 0	Live Zoom	 Zoom / Size
AD	 Audio / Lang I/II	3	 3
TV / PC	 +  Shift + Fav / Marker / PC	2	 2
Search	 +  Shift + Red / Netflix /	1	 1
App	 +  Shift + Green / APP /	T.Opt	 +  Shift + Setup / OPT / Tools
TV / Radio	 TV/Radio /	Energy Saving	 Eject / Surround
Guide	 Guide / EPG / -/--	My APPS	 +  Shift + Smart / List
Info	 Info / Angle		
Recent	 Sleep / Timer		
9	 9		
8	 8		
7	 7		
Live Menu	 Display / Media		
6	 6		

