





































| Originale | Sostituto |
|--|---|
|  Power |  Power |
|  Open/Close |  Eject |
|  Vol+ |  Vol + |
|  Vol- |  Vol - |
|  Mute |  Mute |
|  F |  Menu |
|  Preset/Folder Up |  Ch + |
|  Preset/Folder |  Ch - |
|  Jukebox/Memor |  Smart |
|  Auto Dj |  Media |
|  Delete |  Exit |
|  Repeat |  Text |
|  Play |  Play |
|  Pause |  Pause |
|  Stop |  Stop |
|  Tuning+ |  Right |
|  >>I |  >>I |

| Originale | Sostituto |
|--|--|
|  I<< |  I<< |
|  Tuning- |  Left |
|  Sound Effect |  Dual |
|  Region EQ |  Subt |
|  (i) |  Info |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  Clock |  Shift + AV |
|  Alarm |  TV/R |



