



Originale	Sostituto
 Power	 Power
 USB/My Media	 Media
 Input	 AV
 Stop	 Stop
 Play	 Play
 Pause	 Pause
 <<<	 <<<
 >>>	 >>>
 L/R	 TV/R
 Edge Adj	 Eject
 Sound	 Dual
 Sleep	 Sleep
 Picture	 Shift + Format
 Eco	 Shift + 3D
 Blank	 Pre Ch
 Ratio	 Format
 3D	 3D

Originale	Sostituto
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Page Up	 Ch +
 Page Down	 Ch -
 Settings	 Options
 Still	 Text
 Q.Menu	 D. Menu
 Back	 Back
 Auto	 Info
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Red	 Red





Originale		Sostituto		Originale		Sostituto	
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				

