













































































Originale	Sostituto
 Power	 Power
 Mute	 Mute
 Open/Close	 Eject
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Clear	 Shift + Clear
 Repeat/Tv/Radi	 TV/R
 I<<	 I<<
 <<	 <<

Originale	Sostituto
 >>	 >>
 >>I	 >>I
 Stop	 Stop
 Play	 Play
 Pause	 Pause
 Guide	 Guide
 Rec	 Rec
 PR List	 List
 Timer Rec	 AV
 PR+	 Ch +
 PR-	 Ch -
 Home	 Smart
 Music ID	 Dual
 Info/Display	 Info
 Return	 Back
 Title/PopUp	 Media
 Disc Menu/Rec. List	 Menu





Originale	Sostituto
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Ok
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Marker	 Format
 Search	 Shift + TV/R
 Zoom	 Shift + Eject
 Text	 Text
 Subtitle	 Subt
 Exit	 Exit
 Power Tv	 Shift + Power
 AV/Input Tv	 Shift + AV

Originale	Sostituto
 Vol+ Tv	 Vol +
 Vol- Tv	 Vol -
 PR+ Tv	 Shift + Ch +
 PR- Tv	 Shift + Ch -

