


















































































Originale	Sostituto
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0/Quick Acces	 0
 List/Guide	 Guide
 .../AD/SAP	 Subt
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 CH+	 Ch +

Originale	Sostituto
 CH-	 Ch -
 Source	 AV
 Home	 Smart
 Micro	 List
 Back	 Back
 *	 Menu
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Wheel Up	 >>I
 Wheel Down	 I<<
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue





Originale		Sostituto		Originale		Sostituto	
	Netflix		Media				
	prime video		D. Menu				
	Disney +		Format				
	Rakuten Tv		3D				
	Smart Colors		Shift + Smart				
	O		Options				

